



Mini Coach's Cart and Coach's Cart

The carts with unmatched features in the tennis industry!

Assembly Instructions:

STEP #1: Open box and check that all parts are ready for assembly.

- #A 1 primary cart frame
- #B 1 basket lid (not part of the Mini Coach's Cart package)
- #C 1 main basket
- #D 1 Mesh Divider (use to divide transition from regular balls)
- #E 4 screw-in 4-inch wheels.

STEP #2: Turn frame upside down in the open position and securely screw in the 4 wheels, tightening by hand and then using the wrench to fully secure.

STEP #3: Using a screw driver and pliers, securely tighten the two bolts and lock nuts that allow the frame to fold and unfold. They are located at the center of the "X" frame on each side. Note that we use a lock nut that requires moderate pressure to turn and secure.

STEP #4: Turn cart right side up in open position to lay basket onto the 4 "L" hooks.

NOTES: A lid is included with the full-size Coach's Cart only. It can hang over the side, be stored, or be used when balls need to be secured (lock not included). The hopper hanger on both carts can be used to conveniently transport a ball basket while rolling the cart.